

Table of LNWR Pt Way Crossing Lengths Details for Various Crossing Angles c1909.

Compiled by Brian Nicholls 19/09/2011.

Crossing Angle	'V' Crossing Rail Length From Tip of Blunt Nose to Joint	Wing Rail Length From Tip of Wing to Joint	Check Rail Length Tip to Tip
1 in 1.5	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 1.75	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 2	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 2.25	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 2.5	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 2.75	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 3	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 3.25	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 3.5	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 3.75	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 4	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 4.25	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 4.5	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 4.75	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 5	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 5.25	8ft. 10ins.	8ft. 0ins.	13ft. 6ins.
1 in 5.5	8ft. 10ins.	10ft. 6ins.	13ft. 6ins.
1 in 5.75	8ft. 10ins.	10ft. 6ins.	13ft. 6ins.
1 in 6	11ft. 0ins.	10ft. 6ins.	13ft. 6ins.
1 in 6.5	11ft. 0ins.	10ft. 6ins.	13ft. 6ins.
1 in 7	11ft. 0ins.	10ft. 6ins.	13ft. 6ins.
1 in 7.5	11ft. 0ins.	10ft. 6ins.	13ft. 6ins.
1 in 8	11ft. 0ins.	10ft. 6ins.	13ft. 6ins.
1 in 8.5	11ft. 0ins.	13ft. 0ins.	15ft. 0ins.
1 in 9	11ft. 0ins.	13ft. 0ins.	15ft. 0ins.
1 in 9.5	11ft. 0ins.	13ft. 0ins.	15ft. 0ins.
1 in 10	11ft. 0ins.	13ft. 0ins.	15ft. 0ins.
1 in 10.5	11ft. 0ins.	15ft. 0ins.	15ft. 0ins.
1 in 11	11ft. 0ins.	15ft. 0ins.	15ft. 0ins.
1 in 12	11ft. 0ins.	15ft. 0ins.	15ft. 0ins.
1 in 13	13ft. 6ins.	15ft. 0ins.	15ft. 0ins.
1 in 14	13ft. 6ins.	15ft. 0ins.	15ft. 0ins.
1 in 15	13ft. 6ins.	15ft. 0ins.	15ft. 0ins.
1 in 16	15ft. 6ins.	19ft. 0ins.	19ft. 0ins.
1 in 18	15ft. 6ins.	19ft. 0ins.	19ft. 0ins.
1 in 20	15ft. 6ins.	19ft. 0ins.	19ft. 0ins.